

# HP Integrated Lights-Out Advanced Pack



These activation instructions can also be found at [www.hp.com/go/ice-license](http://www.hp.com/go/ice-license).

Your HP Integrated Lights-Out (iLO) Advanced Pack license key might contain one or more licenses. One license is required for each managed target system.

These instructions assume the network client has a network connection to the iLO or iLO 2 management processor.

To install the iLO Advanced Pack license and enable the iLO Advanced Pack functionality using a supported web browser:

1. Log in to iLO or iLO 2 with a user ID that has the Configure iLO Settings privilege.
2. Click the **Administration** tab, then click **Licensing**.
3. Enter the 5 x 5-character license key in the space provided.
4. Click **Install**. The End User License Agreement (EULA) confirmation displays. The EULA details are available with the license kit.
5. Click **OK** to accept the terms of the EULA enclosed with this product. The licensed features are now enabled.

HP recommends you retain the license key for future reference. The license key is required for technical support and future upgrades.

For activation of iLO Advanced Pack functionality on groups of iLO or iLO 2 processors, use the HP Lights-Out Configuration Utility. Details on this scripting utility and activation using the command line interface are located in the *HP Integrated Lights-Out Management Processor Scripting and Command Line Resource Guide* on the HP website at [www.hp.com/bizsupport](http://www.hp.com/bizsupport). Select **Manuals**, and search for iLO or iLO 2.

This license entitles you to the iLO Advanced features in the current version of iLO 2 firmware at the time of activation. To download the latest firmware and also learn more about iLO features and capabilities, visit [www.hp.com/go/iLO](http://www.hp.com/go/iLO).

## Support and Software Updates

One year of 24x7 Software Technical Support and Software Updates is included with this software. For more information about this service, see [www.hp.com/services/insight](http://www.hp.com/services/insight). After HP processes your support registration, you will receive a Service Agreement Identifier (SAID). To receive the software updates that you are entitled to, you must use your SAID and access the Software Update Manager (SUM) at the HP IT Resource Center (ITRC) home page: [www.itrc.hp.com](http://www.itrc.hp.com).

## Count on HP for Software Support Solutions

The following support upgrade options are available:

- Three years of 24x7 Software Technical Support and Software Updates
- Four years of 24x7 Software Technical Support and Software Updates
- Five years of 24x7 Software Technical Support and Software Updates

To upgrade your support, or for technical issues using Insight Control products purchased through HP, contact an HP support center:

[http://welcome.hp.com/country/us/en/wwwcontact\\_us.html](http://welcome.hp.com/country/us/en/wwwcontact_us.html).

Software is subject to the terms and conditions described in the End User License Agreement (EULA). During installation, be sure to read the EULA carefully before proceeding.

# HP Integrated Lights-Out Advanced Pack



これらのアクティベーション手順は、HPのWebサイト<http://www.hp.com/jp/ice-license>にも記載されています。

HP Integrated Lights-Out (iLO) Advanced Packライセンス キーには、複数のライセンスが含まれる場合があります。管理対象システム1台当たり、1つのライセンスが必要です。

これらの手順は、ネットワーク クライアントがiLOまたはiLO 2 マネジメント プロセッサにネットワーク接続できることを前提としています。

サポートされているWebブラウザを使用して、iLO Advanced Packライセンスをインストールし、iLO Advanced Pack機能を有効にするには、以下の手順に従ってください。

1. iLOの設定権限を持っているユーザIDを使用して、iLOまたはiLO 2にログインします。
2. [管理]タブ、[ライセンス]の順にクリックします。
3. 5×5文字のライセンス キーを、スペースに入力します。
4. [インストール]をクリックします。エンド ユーザ使用許諾契約書 (EULA) の確認画面が表示されます。EULAの内容の詳細は、ライセンス キットから入手できます。
5. この製品に付属のEULAの内容に同意する場合は、[OK]をクリックします。これで、ライセンスを適用された機能が有効になります。

将来使用するために、ライセンス キーを保存しておくことをおすすめします。テクニカル サポートや将来のアップグレードには、ライセンス キーが必要となります。

iLOまたはiLO 2プロセッサのグループでiLO Advanced Packの機能を有効にするには、HP Lights-Out設定ユーティリティを使用します。このスクリプティング ユーティリティおよびコマンド ライン インタフェースを使用したアクティベーションについて詳しくは、HPのWebサイト<http://www.hp.com/jp/manual>にある『HP Integrated Lights-Outマネジメント プロセッサ スクリプティング /コマンド ライン リソース ガイド』を参照してください。

お使いのiLO 2ファームウェアにこのライセンスを適用してアクティベーションを行うと、iLO Advancedの機能が使用できるようになります。最新のファームウェアのダウンロードや、iLOの特長と機能について詳しくは、HPのWebサイト<http://www.hp.com/jp/servers/ilo>を参照してください。

## サポートおよびソフトウェア アップデート

このソフトウェアには、1年間、24時間年中無休のソフトウェア テクニカル サポートおよびソフトウェア アップデートが含まれています。代理店経由でお買い上げいただいたお客様は、製品に同梱の『保守情報登録シート』での登録手続きをお願い致します。(ただし、HPの営業担当から直接お買い上げいただいた場合は、シートでの登録手続きは不要となります。)

このサービスについて詳しくは、保守登録処理完了後に送付されるサービス仕様を参照してください。HPによるお客様のサポート登録処理が完了すると、SAID (Service Agreement Identifier) が送付されます。利用可能なソフトウェア アップデートを受け取るには、HP ITリソース センタ (IT Resource Center) のホームページ <http://www.itrc.hp.com>から、SAIDを使用してソフトウェア アップデート マネージャ (SUM) にアクセスする必要があります。

## 信頼性の高いHPのソフトウェア サポート ソリューション

以下のサポート アップグレード オプションがあります。

- 3年間、24時間年中無休のソフトウェア テクニカル サポート およびソフトウェア アップデート
- 4年間、24時間年中無休のソフトウェア テクニカル サポート およびソフトウェア アップデート
- 5年間、24時間年中無休のソフトウェア テクニカル サポート およびソフトウェア アップデート

サポートのアップグレード、またHPから購入したInsight Control 製品の使用に関する技術的な問題については、HPのWebサイト [http://welcome.hp.com/country/jp/ja/contact\\_us.html](http://welcome.hp.com/country/jp/ja/contact_us.html)から、HPのサポート センタにお問い合わせください。

ソフトウェアは、エンド ユーザ使用許諾契約書 (EULA) の規定に基づき使用されるものとします。インストール時には、必ずEULAをよくお読みいただいてから作業してください。